DC100 USB-C Mini Dock（Page 1）			
Model Name	HDMI 2.0	USB-C 3.2 Gen2	USB-A 3.2 Gen2
BM1403CDA	O	O	O
BM1503CDA	O	O	O
B1400CBA	O	O	O
B1402CBA	O	O	O
B1403CTA	O	O	O
B1403CVA	O	O	O
B1500CBA	O	O	O
B1502CBA	O	O	O
B1503CTA	O	O	O
B1503CVA	O	O	O
B2402CBA	O	O	O
B2402CVA	O	O	O
B2402FBA	O	O	O
B2402FVA	O	O	O
B2502CBA	O	O	O
B2502CVA	O	O	O
B2502FBA	O	O	O
B2502FVA	O	O	O
B3402FBA	O	O	O
B3402FVA	O	O	O
B3404CMA	O	O	O
B3404CVA	O	O	O
B3404CVF	O	O	O
B3405CCA	O	O	O
B3405CVA	O	O	O
B3604CMA	O	O	O
B3604CVA	O	O	O
B3604CVF	O	O	O
B3605CCA	O	O	O
B3605CVA	O	O	O
B5302CBA	O	O	O
B5302FBA	O	O	O
B5402CBA	O	O	O
B5402FBA	O	O	O
B5404CMA	O	O	O
B5404CVA	O	O	O
B5404CVF	O	O	O
B5405CCA	O	O	O
B5405CVA	O	O	O
B5406CMA	O	O	O
B5602CBA	O	O	O
B5602CBN	O	O	O
B5602FBA	O	O	O
B5602FBN	O	O	O
B5604CMA	O	O	O
B5604CVA	O	O	O
B5604CVF	O	O	O
B5605CCA	O	O	O
B5605CVA	O	O	O
B7402FBA	O	O	O
B9400CBA	O	O	O
B9403CVA	O	O	O
B9406CAA	O	O	O
PM1403CDA	O	O	O
PM1503CDA	O	O	O
P1403CVA	O	O	O
P1503CVA	O	O	O
P3405CVA	O	O	O
P3605CVA	O	O	O
P5405CSA	O	O	O

DC100 USB-C Mini Dock（Page 2）

Model Name	HDMI 2.0	USB-C 3.2 Gen2	USB-A 3.2 Gen2
BR1100CKA	O	O	O
BR1100FKA	O	O	O
BR1104CGA	O	O	O
BR1104CTA	O	O	O
BR1104FGA	O	O	O
BR1104FTA	O	O	O
BR1204CGA	O	O	O
BR1204CTA	O	O	O
BR1204FGA	O	O	O
BR1204FTA	O	O	O
BR1402CGA	O	O	O
BR1402FGA	O	O	O
CM1402CM2A	O	O	O
CM1402FM2A	O	O	O
CM3001DM2A	O	O	O
CR1100CKA	O	O	O
CR1100FKA	O	O	O
CR1104CGA	O	O	O
CR1104CTA	O	O	O
CR1104FGA	O	O	O
CR1104FTA	O	O	O
CR1204CGA	O	O	O
CR1204CTA	O	O	O
CR1204FGA	O	O	O
CR1204FTA	O	O	O
CX1102CKA	O	O	O
CX1102FKA	O	O	O
CX1400CKA	O	O	O
CX1400FKA	O	O	O
CX1405CKA	O	O	O
CX1405CTA	O	O	O
CX1500CKA	O	O	O
CX1500FKA	O	O	O
CX1505CKA	O	O	O
CX1505CTA	O	O	O
CX1700CKA	O	O	O
CX3401FBA	O	O	O
CX3402CBA	O	O	O
CX3402CVA	O	O	O
CX5403CMA	O	O	O
CX5601FBA	O	O	O
CZ1104CM2A	O	O	O
CZ1104FM2A	O	O	O
CZ1204CM2A	O	O	O
CZ1204FM2A	O	O	O
L2402CYA	O	O	O
L2402FYA	O	O	O
L2502CYA	O	O	O
L2502FYA	O	O	O
L5404CHA	O	O	O

DC201 Dual 4K USB-C Dock（Page 1）

Model Name	USB-C1 3.2 Gen2 DP1.4	USB-C2 3.2 Gen2 PD	USB-A 3.2 Gen2	HDMI2.1	RJ45 1GbE
BM1403CDA	O	O	O	O	O
BM1503CDA	O	O	O	O	O
B1400CBA	O	O	O	O	O
B1402CBA	O	O	O	O	O
B1402CGA	O	O	O	O	O
B1402CVA	O	O	O	O	O
B1403CTA	O	O	O	O	O
B1403CVA	O	O	O	O	O
B1500CBA	O	O	O	O	O
B1502CBA	O	O	O	O	O
B1502CGA	O	O	O	O	O
B1502CVA	O	O	O	O	O
B1503CTA	O	O	O	O	O
B1503CVA	O	O	O	O	O
B2402CBA	O	O	O	O	O
B2402CVA	O	O	O	O	O
B2402FBA	O	O	O	O	O
B2402FVA	O	O	O	O	O
B2502CBA	O	O	O	O	O
B2502CVA	O	O	O	O	O
B2502FBA	O	O	O	O	O
B2502FVA	O	O	O	O	O
B3402FBA	O	O	O	O	O
B3402FVA	O	O	O	O	O
B3404CMA	O	O	O	O	O
B3404CVA	O	O	O	O	O
B3404CVF	O	O	O	O	O
B3405CCA	O	O	O	O	O
B3405CVA	O	O	O	O	O
B3604CMA	O	O	O	O	O
B3604CVA	O	O	O	O	O
B3604CVF	O	O	O	O	O
B3605CCA	O	O	O	O	O
B3605CVA	O	O	O	O	O
B5302CBA	O	O	O	O	O
B5302FBA	O	O	O	O	O
B5402CBA	O	O	O	O	O
B5402CVA	O	O	O	O	O
B5402FBA	O	O	O	O	O
B5402FVA	O	O	O	O	O
B5404CMA	O	O	O	O	O
B5404CVA	O	O	O	O	O
B5404CVF	O	O	O	O	O
B5405CCA	O	O	O	O	O
B5405CVA	O	O	O	O	O
B5602CBA	O	O	O	O	O
B5602CBN	O	O	O	O	O
B5602CVA	O	O	O	O	O
B5602CVN	O	O	O	O	O
B5602FBA	O	O	O	O	O
B5602FBN	O	O	O	O	O
B5604CMA	O	O	O	O	O
B5604CVA	O	O	O	O	O
B5604CVF	O	O	O	O	O
B5605CCA	O	O	O	O	O
B5605CVA	O	O	O	O	O
B6602FC2	O	O	O	O	O
B7402FBA	O	O	O	O	O
B9400CBA	O	O	O	O	O
B9403CVA	O	O	O	O	O
B9406CAA	O	O	O	O	O

DC201 Dual 4K USB-C Dock（Page 2）

Model Name	USB-C1 3.2 Gen2 DP1.4	USB-C2 3.2 Gen2 PD	USB-A 3.2 Gen2	HDMI2.1	RJ45 1GbE
PM1403CDA	O	O	O	O	O
PM1503CDA	O	O	O	O	O
P1403CVA	O	O	O	O	O
P1503CVA	O	O	O	O	O
P3405CVA	O	O	O	O	O
P3605CVA	O	O	O	O	O
P5405CSA	O	O	O	O	O
BR1100CKA	O	O	O	O	O
BR1100FKA	O	O	O	O	O
BR1102CGA	O	O	O	O	O
BR1102FGA	O	O	O	O	O
BR1104CGA	O	O	O	O	O
BR1104FGA	O	O	O	O	O
BR1104CTA	O	O	O	O	O
BR1104FTA	O	O	O	O	O
BR1204CGA	O	O	O	O	O
BR1204FGA	O	O	O	O	O
BR1204CTA	O	O	O	O	O
BR1204FTA	O	O	O	O	O
BR1402CGA	O	O	O	O	O
BR1402FGA	O	O	O	O	O
CM1402CM2A	O	O	O	O	O
CM1402FM2A	O	O	O	O	O
CM3001DM2A	O	O	O	O	O
CR1100CKA	O	O	O	O	O
CR1100FKA	O	O	O	O	O
CR1102CGA	O	O	O	O	O
CR1102FGA	O	O	O	O	O
CR1104CGA	O	O	O	O	O
CR1104FGA	O	O	O	O	O
CR1104CTA	O	O	O	O	O
CR1104FTA	O	O	O	O	O
CR1204CGA	O	O	O	O	O
CR1204FGA	O	O	O	O	O
CR1204CTA	O	O	O	O	O
CR1204FTA	O	O	O	O	O
CX1102CKA	O	O	O	O	O
CX1102FKA	O	O	O	O	O
CX1400CKA	O	O	O	O	O
CX1400FKA	O	O	O	O	O
CX1405CKA	O	O	O	O	O
CX1405CTA	O	O	O	O	O
CX1500CKA	O	O	O	O	O
CX1500FKA	O	O	O	O	O
CX1505CKA	O	O	O	O	O
CX1505CTA	O	O	O	O	O
CX1700CKA	O	O	O	O	O
CX3401FBA	O	O	O	O	O
CX3402CBA	O	O	O	O	O
CX3402CVA	O	O	O	O	O
CX5403CMA	O	O	O	O	O
CX5601FBA	O	O	O	O	O
CZ1104CM2A	O	O	O	O	O
CZ1104FM2A	O	O	O	O	O
CZ1204CM2A	O	O	O	O	O
CZ1204FM2A	O	O	O	O	O
L5404CHA	O	O	O	O	O

DC300 Triple Display USB-C Dock（Page1）

Model Name	HDMI 2.0	DP 1.4	USB-C DP 1.4	USB-C 3.2 Gen2	USB-A 3.2 Gen2	USB-A 3.2 Gen1	RJ45 1GbE	Audio Combo	SD card reader 4.0	DC Jack(4.5 phi)	PXE	WOL	MAPT	Power button with indicator LED
BM1403CDA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
BM1503CDA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B1400CBA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B1402CBA	O	O	O	O	O	O	O	O	O	O	X	X	X	O
B1402CVA	O	O	O	O	O	O	O	O	O	O	X	X	X	O
B1403CTA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B1403CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B1500CBA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B1502CBA	O	O	O	O	O	O	O	O	O	O	X	X	X	O
B1502CVA	O	O	O	O	O	O	O	O	O	O	X	X	X	O
B1503CTA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B1503CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B2402CBA	O	O	O	O	O	O	O	O	O	O	X	X	X	O
B2402CVA	O	O	O	O	O	O	O	O	O	O	X	X	X	O
B2402FBA	O	O	O	O	O	O	O	O	O	O	X	X	X	O
B2402FVA	O	O	O	O	O	O	O	O	O	O	X	X	X	O
B2502CBA	O	O	O	O	O	O	O	O	O	O	X	X	X	O
B2502CVA	O	O	O	O	O	O	O	O	O	O	X	X	X	O
B2502FBA	O	O	O	O	O	O	O	O	O	O	X	X	X	O
B2502FVA	O	O	O	O	O	O	O	O	O	O	X	X	X	O
B3402FBA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3404CMA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3404CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3404CVF	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3405CCA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3405CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3604CMA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3604CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3604CVF	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3605CCA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3605CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B5302CBA	O	O	O	O	O	O	O	O	O	O	X	X	X	O
B5302FBA	O	O	O	O	O	O	O	O	O	O	X	X	X	O
B5402CBA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B5402CVA	O	O	O	O	O	O	O	O	O	O	X	X	X	O
B5402FBA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B5402FVA	O	O	O	O	O	O	O	O	O	O	X	X	X	O
B5404CMA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B5404CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B5404CVF	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B5405CCA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B5405CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O

1. The power button of DC300 can't be synchronized with the laptop to turn on both devices simultaneously. Please refer to the individual laptop specifications for full details. Press the power-button can turn on/off LED and open/shot down DC300's display signal.
2. When connected to non Thunderbolt or display out systems, DC300 will not retain the respective Thunderbolt or display out function.

This document was last updated on May, 2026.

DC300 Triple Display USB-C Dock（Page 2）

Model Name	HDMI 2.0	DP 1.4	USB-C DP 1.4	USB-C 3.2 Gen2	USB-A 3.2 Gen2	USB-A 3.2 Gen1	RJ45 1GbE	Audio Combo	SD card reader 4.0	DC Jack(4.5 phi)	PXE	WOL	MAPT	Power button with indicator LED
B5602CBA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B5602CBN	O	O	O	O	O	O	O	O	O	O	X	X	X	O
B5602CVA	O	O	O	O	O	O	O	O	O	O	X	X	X	O
B5602CVN	O	O	O	O	O	O	O	O	O	O	X	X	X	O
B5602FBA	O	O	O	O	O	O	O	O	O	O	X	X	X	O
B5602FBN	O	O	O	O	O	O	O	O	O	O	X	X	X	O
B5604CMA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B5604CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B5604CVF	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B5605CCA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B5605CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B7402FBA	O	O	O	O	O	O	O	O	O	O	X	X	X	O
B7402FVA	O	O	O	O	O	O	O	O	O	O	X	X	X	O
B9400CBA	O	O	O	O	O	O	O	O	O	O	X	X	X	O
B9403CVA	O	O	O	O	O	O	O	O	O	O	X	X	X	O
B9406CAA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
PM1403CDA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
PM1503CDA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
PM3406CKA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
PM3606CKA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
P1403CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
P1503CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
P3405CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
P3605CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
P5404CSA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
P5405CSA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
BR1104CTA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
BR1104FTA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
BR1204CTA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
BR1204FTA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
CX3401FBA	O	O	O	O	O	O	O	O	O	O	X	X	X	X[1]
CX3402CBA	O	O	O	O	O	O	O	O	O	O	X	X	X	X[1]
CX3402CVA	O	O	O	O	O	O	O	O	O	O	X	X	X	X[1]
CX5601FBA	O	O	O	O	O	O	O	O	O	O	X	X	X	X[1]
L2402CYA	O	O	O	O	O	O	O	O	O	O	X	X	X	O
L2402FYA	O	O	O	O	O	O	O	O	O	O	X	X	X	O
L2502CYA	O	O	O	O	O	O	O	O	O	O	X	X	X	O
L2502FYA	O	O	O	O	O	O	O	O	O	O	X	X	X	O
L5404CHA	O	O	O	O	O	O	O	O	O	O	O	O	O	O

1. The power button of DC300 can't be synchronized with the laptop to turn on both devices simultaneously. Please refer to the individual laptop specifications for full details. Press the power-button can turn on/off LED and open/shot down DC300's display signal.
2. When connected to non Thunderbolt or display out systems, DC300 will not retain the respective Thunderbolt or display out function.

This document was last updated on May, 2026.

DC301 Triple Display USB-C Dock（Page 1）

Model Name	HDMI 2.0	DP 1.4 ①	DP 1.4 ②	USB-C 3.2 Gen2 PD	USB-C 3.2 Gen2	USB-A 3.2 Gen2	USB-A 3.2 Gen1	RJ45 1GbE	Audio Combo	SD card reader 4.0	DC Jack(4.5 phi)	PXE	WOL	MAPT	Power button with indicator LED
BM1403CDA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
BM1503CDA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B1403CTA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B1403CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B1503CTA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B1503CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B2402CBA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B2402CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B2402FBA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B2402FVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B2502CBA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B2502CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B2502FBA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B2502FVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3402FBA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3404CMA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3404CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3404CVF	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3405CAA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3405CCA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3405CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3406CCA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3604CMA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3604CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3604CVF	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3605CAA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3605CCA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3605CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3606CCA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B5302CBA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B5302FBA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B5404CMA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B5404CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B5405CAA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O

1. The power button of DC301 can't be synchronized with the laptop to turn on both devices simultaneously. Please refer to the individual laptop specifications for full details. Press the power-button can turn on/off LED and open/shot down DC301's display signal.
2. When connected to non Thunderbolt or display out systems, DC301 will not retain the respective Thunderbolt or display out function.

This document was last updated on May, 2026.

DC301 Triple Display USB-C Dock（Page 2）

Model Name	HDMI 2.0	DP 1.4 ①	DP 1.4 ②	USB-C 3.2 Gen2 PD	USB-C 3.2 Gen2	USB-A 3.2 Gen2	USB-A 3.2 Gen1	RJ45 1GbE	Audio Combo	SD card reader 4.0	DC Jack(4.5 phi)	PXE	WOL	MAPT	Power button with indicator LED
B5405CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B5604CMA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B5604CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B5605CAA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B5605CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B9400CBA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B9403CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B9406CAA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
BM3406CGA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
BM3406CGAZ	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
BM3406CHA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
BM3606CGA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
BM3606CGAZ	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
BM3606CHA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
L5404CHA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
PM1403CDA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
P1403CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
P1503CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
P3405CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
P3406CCA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
P3605CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
P3606CCA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
P5405CAA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
P5405CSA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
P5406CCA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
P5605CAA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
P5606CCA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
PM3406CHA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O

1. The power button of DC301 can't be synchronized with the laptop to turn on both devices simultaneously. Please refer to the individual laptop specifications for full details. Press the power-button can turn on/off LED and open/shot down DC301's display signal.
2. When connected to non Thunderbolt or display out systems, DC301 will not retain the respective Thunderbolt or display out function.

This document was last updated on May, 2026.

DC301 Triple Display USB-C Dock（Page 3）

Model Name	HDMI 2.0	DP 1.4 ①	DP 1.4 ②	USB-C 3.2 Gen2 PD	USB-C 3.2 Gen2	USB-A 3.2 Gen2	USB-A 3.2 Gen1	RJ45 1GbE	Audio Combo	SD card reader 4.0	DC Jack(4.5 phi)	PXE	WOL	MAPT	Power button with indicator LED
PM3606CHA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
PM5406CGA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
PM5406CKA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
PM5606CGA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
PM5606CKA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
BR1104CGA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
BR1104CTA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
BR1104FGA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
BR1104FTA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
BR1204CGA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
BR1204CTA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
BR1204FGA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
BR1204FTA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
CM1402FM2A	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
CM3001DM2A	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
CR1104CTA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
CR1104FTA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
CR1204CTA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
CR1204FTA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
CX1405CKA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
CX1405CTA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
CX1505CKA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
CX1505CTA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
CX3402CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
CX5403CMA	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
CZ1104CM2A	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
CZ1104FM2A	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
CZ1204CM2A	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
CZ1204FM2A	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O

1. The power button of DC301 can't be synchronized with the laptop to turn on both devices simultaneously. Please refer to the individual laptop specifications for full details. Press the power-button can turn on/off LED and open/shot down DC301's display signal.
2. When connected to non Thunderbolt or display out systems, DC301 will not retain the respective Thunderbolt or display out function.
This document was last updated on May, 2026.

DC310 USB-C Stand Dock（Page 1）

Model Name	HDMI 2.0_port 1	HDMI 2.0_port 2	USB-C 3.2 Gen2	USB-A 3.2 Gen2 BC	USB-A 3.2 Gen2	USB-A 3.2 Gen1_port 1	USB-A 3.2 Gen1_port 2	RJ45 1GbE	Audio Combo	DC Jack(4.5 phi)	PXE	WOL	MAPT	Power button with indicator LED
BM1403CDA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B1403CTA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B1403CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B1503CTA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B1503CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B2402CBA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B2402CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B2402FBA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B2403FVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B2502CBA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B2502CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B2502FBA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B2502FVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3404CMA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3404CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3404CVF	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3405CCA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3405CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3604CMA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3604CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3604CVF	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3605CCA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B3605CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B5404CMA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B5404CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B5405CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B5604CMA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B5604CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B5605CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B9403CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
B9406CAA	O	O	O	O	O	O	O	O	O	O	O	O	O	O

1. The power button of DC310 can't be synchronized with the laptop to turn on both devices simultaneously. Please refer to the individual laptop specifications for full details. Press the power-button can turn on/off LED and open/shot down DC310's display signal.
2. When connected to non Thunderbolt or display out systems, DC300 will not retain the respective Thunderbolt or display out function.
This document was last updated on May, 2026.

DC310 USB-C Stand Dock（Page 2）

Model Name	HDMI 2.0_port 1	HDMI 2.0_port 2	USB-C 3.2 Gen2	USB-A 3.2 Gen2 BC	USB-A 3.2 Gen2	USB-A 3.2 Gen1_port 1	USB-A 3.2 Gen1_port 2	RJ45 1GbE	Audio Combo	DC Jack(4.5 phi)	PXE	WOL	MAPT	Power button with indicator LED
L5404CHA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
PM1403CDA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
P1403CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
P1503CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
P3405CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
P3605CVA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
P5405CSA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
BR1104CGA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
BR1104CTA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
BR1104FGA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
BR1104FTA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
BR1204CGA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
BR1204CTA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
BR1204FGA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
BR1204FTA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
CM1402FM2A	O	O	O	O	O	O	O	O	X	O	X	X	X	X
CM3001DM2A	O	O	X	X	X	X	X	O	O	O	X	X	X	X
CR1104CTA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
CR1104FTA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
CR1204CTA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
CR1204FTA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
CX1405CKA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
CX1405CTA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
CX1505CKA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
CX1505CTA	O	O	O	O	O	O	O	O	O	O	O	O	O	O
CX3402CVA	X	X	O	O	O	O	O	O	O	O	X	X	X	X
CX5403CMA	X	X	X	X	X	X	X	X	X	X	X	X	X	X
CZ1104CM2A	O	O	O	O	O	O	O	O	X	O	X	X	X	X
CZ1104FM2A	O	O	O	O	O	O	O	O	X	O	X	X	X	X
CZ1204CM2A	O	O	O	O	O	O	O	O	X	O	X	X	X	X
CZ1204FM2A	O	O	O	O	O	O	O	O	X	O	X	X	X	X

1. The power button of DC310 can't be synchronized with the laptop to turn on both devices simultaneously. Please refer to the individual laptop specifications for full details. Press the power-button can turn on/off LED and open/shot down DC310's display signal.
2. When connected to non Thunderbolt or display out systems, DC300 will not retain the respective Thunderbolt or display out function.

This document was last updated on May, 2026.

DC500 Triple 4K TBT 4 Dock（Page 1）

Model Name	Thunderbolt™ 4	HDMI 2.1	SD card reader 4.0 (UHS II)	Micro SD card reader (UHS II)	USB-A 3.2 Gen2	USB-A 2.0	RJ45 2.5 GbE	Audio combo jack	DC jack(4.5 phi)	PXE	WOL	MAPT	Power button with indicator LED
BM1403CDA	O	O	O	O	O	O	O	O	O	O	O	O	O
B1400CBA	O	O	O	O	O	O	O	O	O	O	O	O	O
B1402CBA	x[2]	O	O	O	O	O	O	O	O	O	O	O	O
B1402CGA	x[2]	O	O	O	O	O	O	O	O	O	O	O	O
B1402CVA	x[2]	O	O	O	O	O	O	O	O	O	O	O	O
B1403CTA	O	O	O	O	O	O	O	O	O	O	O	O	O
B1403CVA	O	O	O	O	O	O	O	O	O	O	O	O	O
B1500CBA	O	O	O	O	O	O	O	O	O	O	O	O	O
B1502CBA	x[2]	O	O	O	O	O	O	O	O	O	O	O	O
B1502CGA	x[2]	O	O	O	O	O	O	O	O	O	O	O	O
B1502CVA	x[2]	O	O	O	O	O	O	O	O	O	O	O	O
B1503CTA	O	O	O	O	O	O	O	O	O	O	O	O	O
B1503CVA	O	O	O	O	O	O	O	O	O	O	O	O	O
B2402CBA	O	O	O	O	O	O	O	O	O	O	O	O	O
B2402CVA	O	O	O	O	O	O	O	O	O	O	O	O	O
B2402FBA	O	O	O	O	O	O	O	O	O	O	O	O	O
B2402FVA	O	O	O	O	O	O	O	O	O	O	O	O	O
B2502CBA	O	O	O	O	O	O	O	O	O	O	O	O	O
B2502CVA	O	O	O	O	O	O	O	O	O	O	O	O	O
B2502FBA	O	O	O	O	O	O	O	O	O	O	O	O	O
B2502FVA	O	O	O	O	O	O	O	O	O	O	O	O	O
B3402FBA	O	O	O	O	O	O	O	O	O	O	O	O	O
B3402FVA	O	O	O	O	O	O	O	O	O	O	O	O	x[1]
B3404CMA	O	O	O	O	O	O	O	O	O	O	O	O	O
B3404CVA	O	O	O	O	O	O	O	O	O	X	O	O	O
B3404CVF	O	O	O	O	O	O	O	O	O	O	O	O	O
B3405CCA	O	O	O	O	O	O	O	O	O	O	O	O	O
B3405CVA	O	O	O	O	O	O	O	O	O	O	O	O	O
B3604CMA	O	O	O	O	O	O	O	O	O	O	O	O	O
B3604CVA	O	O	O	O	O	O	O	O	O	X	O	O	O
B3604CVF	O	O	O	O	O	O	O	O	O	O	O	O	O
B3605CCA	O	O	O	O	O	O	O	O	O	O	O	O	O
B3605CVA	O	O	O	O	O	O	O	O	O	O	O	O	O
B5302CBA	O	O	O	O	O	O	O	O	O	O	O	O	O
B5302FBA	O	O	O	O	O	O	O	O	O	O	O	O	O
B5402CBA	O	O	O	O	O	O	O	O	O	O	O	O	O
B5402CVA	O	O	O	O	O	O	O	O	O	O	O	O	O
B5402FBA	O	O	O	O	O	O	O	O	O	O	O	O	O
B5402FVA	O	O	O	O	O	O	O	O	O	O	O	O	O
B5404CMA	O	O	O	O	O	O	O	O	O	O	O	O	O
B5404CVA	O	O	O	O	O	O	O	O	O	X	O	O	O
B5404CVF	O	O	O	O	O	O	O	O	O	O	O	O	O
B5405CCA	O	O	O	O	O	O	O	O	O	O	O	O	O
B5405CVA	O	O	O	O	O	O	O	O	O	O	O	O	O

1.Press the power-button can turn on/off DC500. The power button of DC500 can't be synchronized with the laptop to turn on both devices simultaneously. Please refer to the individual laptop specifications for full details.

2.When connected to non Thunderbolt or display out systems, DC500 will not retain the respective Thunderbolt or display out function.

This document was last updated on May, 2026.

DC500 Triple 4K TBT 4 Dock（Page 2）

Model Name	Thunderbolt™ 4	HDMI 2.1	SD card reader 4.0 (UHS II)	Micro SD card reader (UHS II)	USB-A 3.2 Gen2	USB-A 2.0	RJ45 2.5 GbE	Audio combo jack	DC jack(4.5 phi)	PXE	WOL	MAPT	Power button with indicator LED
B5602CBA	O	O	O	O	O	O	O	O	O	O	O	O	O
B5602CBN	O	O	O	O	O	O	O	O	O	O	O	O	O
B5602CVA	O	O	O	O	O	O	O	O	O	O	O	O	O
B5602CVN	O	O	O	O	O	O	O	O	O	O	O	O	O
B5602FBA	O	O	O	O	O	O	O	O	O	O	O	O	O
B5602FBN	O	O	O	O	O	O	O	O	O	O	O	O	O
B5604CMA	O	O	O	O	O	O	O	O	O	O	O	O	O
B5604CVA	O	O	O	O	O	O	O	O	O	X	O	O	O
B5604CVF	O	O	O	O	O	O	O	O	O	O	O	O	O
B5605CCA	O	O	O	O	O	O	O	O	O	O	O	O	O
B5605CVA	O	O	O	O	O	O	O	O	O	O	O	O	O
B7402FBA	O	O	O	O	O	O	O	O	O	O	O	O	O
B7402FVA	O	O	O	O	O	O	O	O	O	O	O	O	O
B9400CBA	O	O	O	O	O	O	O	O	O	O	O	O	O
B9403CVA	O	O	O	O	O	O	O	O	O	O	O	O	O
B9406CAA	O	O	O	O	O	O	O	O	O	O	O	O	O
PM1403CDA	O	O	O	O	O	O	O	O	O	O	O	O	O
PM3406CKA	O	O	O	O	O	O	O	O	O	O	O	O	O
PM3606CKA	O	O	O	O	O	O	O	O	O	O	O	O	O
P1403CVA	O	O	O	O	O	O	O	O	O	O	O	O	O
P3405CVA	O	O	O	O	O	O	O	O	O	O	O	O	O
P3605CVA	O	O	O	O	O	O	O	O	O	O	O	O	O
P5404CSA	O	O	O	O	O	O	O	O	O	O	O	O	O
BR1102CGA	x[2]	O	O	O	O	O	O	O	O	O	O	O	O
BR1102FGA	x[2]	O	O	O	O	O	O	O	O	O	O	O	O
BR1104CGA	x[2]	O	O	O	O	O	O	O	O	O	O	O	O
BR1104CTA	x[2]	O	O	O	O	O	O	O	O	O	O	O	O
BR1104FGA	x[2]	O	O	O	O	O	O	O	O	O	O	O	O
BR1104FTA	x[2]	O	O	O	O	O	O	O	O	O	O	O	O
BR1204CGA	x[2]	O	O	O	O	O	O	O	O	O	O	O	O
BR1204CTA	x[2]	O	O	O	O	O	O	O	O	O	O	O	O
BR1204FGA	x[2]	O	O	O	O	O	O	O	O	O	O	O	O
BR1204FTA	x[2]	O	O	O	O	O	O	O	O	O	O	O	O
BR1402CGA	x[2]	O	O	O	O	O	O	O	O	O	O	O	O
BR1402FGA	x[2]	O	O	O	O	O	O	O	O	O	O	O	O
CR1102CGA	x[2]	O	O	O	O	O	O	O	O	O	O	O	x[1]
CR1102FGA	x[2]	O	O	O	O	O	O	O	O	O	O	O	x[1]
CR1104CGA	x[2]	O	O	O	O	O	O	O	O	O	O	O	x[1]
CR1104FGA	x[2]	O	O	O	O	O	O	O	O	O	O	O	x[1]
CR1204CGA	x[2]	O	O	O	O	O	O	O	O	O	O	O	x[1]
CR1204FGA	x[2]	O	O	O	O	O	O	O	O	O	O	O	x[1]
CX3401FBA	x[2]	O	O	O	O	O	O	O	O	O	O	O	x[1]
CX3402CBA	x[2]	O	O	O	O	O	O	O	O	O	O	O	x[1]
CX3402CVA	x[2]	O	O	O	O	O	O	O	O	O	O	O	x[1]
CX5403CMA	O	O	O	O	O	O	O	O	O	O	O	O	x[1]
CX5601FBA	O	O	O	O	O	O	O	O	O	O	O	O	x[1]
L2402CYA	O	O	O	O	O	O	O	O	O	O	O	O	O
L2402FYA	x[2]	O	O	O	O	O	O	O	O	O	O	O	O
L2502CYA	O	O	O	O	O	O	O	O	O	O	O	O	O
L2502FYA	x[2]	O	O	O	O	O	O	O	O	O	O	O	O
L5404CHA	O	O	O	O	O	O	O	O	O	O	O	O	O

1.Press the power-button can turn on/off DC500. The power button of DC500 can't be synchronized with the laptop to turn on both devices simultaneously. Please refer to the individual laptop specifications for full details.

2.When connected to non Thunderbolt or display out systems, DC500 will not retain the respective Thunderbolt or display out function.

This document was last updated on May, 2026.